


RS76S Spreader



Accessories for Shindaiwa products can be found at:
www.shindaiwa-usa.com/products/accessories.aspx

PARTS LIST2
PARTS LIST3

PARTS LIST



NO.	PART NUMBER	QTY.	DESCRIPTION
1	P15574	1	Hopper Assembly
2	P14604	1	+Hopper
3	P14001	2	+Discharge Chute Knob
4	P15144	1	+Discharge Chute & Shut-Off Plate Guides
5	P13353	1	+Shut-Off Plate
6	P15521	1	+Rate Plate
7	P12704	1	+Rate Control Knob
8	P12708	1	+Pointer
9	P15527-01	1	+Spring Housing Assembly
10	P14022	2	Screen Clips
11	P14603-04	1	Hopper Screen
12	P15508	1	Handle Brace/Leg
13	P14916	1	Control Tube
14	P15498	1	Upper Handle
15	P15513	1	Handle Lever Ass'y
16	P14870	2	Handle Grip
17	P14312-1	1	Impeller Shaft Bearing
18	P790120W	2	Wheel
19	P15641	1	Impeller Shaft
20	P14833	1	Pinion Gear
21	P14832	1	Axle Gear
22	P14837	2	Gear Cover
23	P14868-1	3	Gear Cover Clamps
24	P14834	1	Gear Support
25	P14971	1	Axle Collar w/Set Screw
26	P15518	1	Axle
27	P16412	4	Axle Bearing
28	P15517	1	Frame Assembly
29	P14625	1	Impeller
30	P16233	1	Hopper Label
31	P14510	1	Agitator
32	P15579	1	Fastener Package
33	P14606-1	1	Hopper Cover